

# Dimensions of pocket doorframe LATENTE STANDARD

All dimensions are in millimetres.

Maximum thickness of door leaf (F) for K 100: 68.

## MOUNTING PANELS

50 mm + 12 mm half track + 3 mm wide shadow groove.

### LATENTE STANDARD 1970 mm

Height of net passage after installation of mounting panels (J): 1970.

Total height of the pocket doorframe (H): 2053.

Standard height of wooden door leaf (L): 1985.

Net passage after mounting panels min. (D × J)	Overall dimensions of pocket doorframe (E × H)	Width of metal pocket (A)	Width of passage after installation of pocket doorframe (B)	Net passage after installation of mounting panels min. (C × L)	Dimensions of rough construction opening in drywall	Recommended dimensions for rough structural hole in masonry systems
600 × 1970	1392 × 2053	690	680	650 × 1985	1392 × 2053	1432 × 2073
700 × 1970	1592 × 2053	790	780	750 × 1985	1592 × 2053	1632 × 2073
800 × 1970	1792 × 2053	890	880	850 × 1985	1792 × 2053	1832 × 2073
900 × 1970	1992 × 2053	990	980	950 × 1985	1992 × 2053	2032 × 2073
1000 × 1970	2192 × 2053	1090	1080	1050 × 1985	2192 × 2053	2232 × 2073
1100 × 1970	2392 × 2053	1190	1180	1150 × 1985	2392 × 2053	2432 × 2073
1200 × 1970	2592 × 2053	1290	1280	1250 × 1985	2592 × 2053	2632 × 2073

### LATENTE STANDARD 2100 mm

Height of net passage after installation of mounting panels (J): 2100.

Total height of the pocket doorframe (H): 2183.

Standard height of wooden door leaf (L): 2115.

Net passage after mounting panels min. (D × J)	Overall dimensions of pocket doorframe (E × H)	Width of metal pocket (A)	Width of passage after installation of pocket doorframe (B)	Net passage after installation of mounting panels min. (C × L)	Dimensions of rough construction opening in drywall	Recommended dimensions for rough structural hole in masonry systems
600 × 2100	1392 × 2183	690	680	650 × 2115	1392 × 2183	1432 × 2203
700 × 2100	1592 × 2183	790	780	750 × 2115	1592 × 2183	1632 × 2203
800 × 2100	1792 × 2183	890	880	850 × 2115	1792 × 2183	1832 × 2203
900 × 2100	1992 × 2183	990	980	950 × 2115	1992 × 2183	2032 × 2203
1000 × 2100	2192 × 2183	1090	1080	1050 × 2115	2192 × 2183	2232 × 2203
1100 × 2100	2392 × 2183	1190	1180	1150 × 2115	2392 × 2183	2432 × 2203
1200 × 2100	2592 × 2183	1290	1280	1250 × 2115	2592 × 2183	2632 × 2203

A – width of sheet metal pocket

B – width of passage after installation of pocket doorframe

C – standard width of door leaf

D – width of net passage after installation of mounting panels

E – total width of pocket doorframe

F – maximum thickness of door leaf

G – internal dimensions of frame

H – total height of pocket doorframe

I – floor–rail height (verification of positioning on the finished floor)

J – height of net passage after installation of mounting panels

K – external dimensions of pocket doorframe

L – standard height of door leaf

P – Minimum thickness of finished partition

## MOUNTING PANELS

65 mm + Ø mm wide half-groove + 1 mm wide shadow groove

### LATENTE STANDARD 1970 mm

Height of net passage after installation of mounting panels (J): 1970.

Total height of the pocket doorframe (H): 2054.

Standard height of wooden door leaf (L): 1985.

Net passage after mounting panels min. (D × J)	Overall dimensions of pocket doorframe (E × H)	Width of metal pocket (A)	Width of passage after installation of pocket doorframe (B)	Net passage after installation of mounting panels min. (C × L)	Dimensions of rough construction opening in drywall	Recommended dimensions for rough structural hole in masonry systems
600 × 1970	1388 × 2054	690	676	650 × 1985	1388 × 2054	1428 × 2074
700 × 1970	1588 × 2054	790	776	750 × 1985	1588 × 2054	1628 × 2074
800 × 1970	1788 × 2054	890	876	850 × 1985	1788 × 2054	1828 × 2074
900 × 1970	1988 × 2054	990	976	950 × 1985	1988 × 2054	2028 × 2074
1000 × 1970	2188 × 2054	1090	1076	1050 × 1985	2188 × 2054	2228 × 2074
1100 × 1970	2388 × 2054	1190	1176	1150 × 1985	2388 × 2054	2428 × 2074
1200 × 1970	2588 × 2054	1290	1276	1250 × 1985	2588 × 2054	2628 × 2074

### LATENTE STANDARD 2100 mm

Height of net passage after installation of mounting panels (J): 2100.

Total height of the pocket doorframe (H): 2184.

Standard height of wooden door leaf (L): 2115.

Net passage after mounting panels min. (D × J)	Overall dimensions of pocket doorframe (E × H)	Width of metal pocket (A)	Width of passage after installation of pocket doorframe (B)	Net passage after installation of mounting panels min. (C × L)	Dimensions of rough construction opening in drywall	Recommended dimensions for rough structural hole in masonry systems
600 × 2100	1388 × 2184	690	676	650 × 2115	1388 × 2184	1428 × 2204
700 × 2100	1588 × 2184	790	776	750 × 2115	1588 × 2184	1628 × 2204
800 × 2100	1788 × 2184	890	876	850 × 2115	1788 × 2184	1828 × 2204
900 × 2100	1988 × 2184	990	976	950 × 2115	1988 × 2184	2028 × 2204
1000 × 2100	2188 × 2184	1090	1076	1050 × 2115	2188 × 2184	2228 × 2204
1100 × 2100	2388 × 2184	1190	1176	1150 × 2115	2388 × 2184	2428 × 2204
1200 × 2100	2588 × 2184	1290	1276	1250 × 2115	2588 × 2184	2628 × 2204